

Track system 3-Phases 230V, Alnitak 24-30W, Article No.: 707110-707115

Dear customer,

thank you for deciding to purchase our product. The product fulfils the requirements of effective European and national guidelines.

To maintain the condition of the product and to ensure safe operation, you - as the user - must observe the product notes and the operation manual! They contain important information for the start-up and handling. It is important, therefore, that these documents are archived carefully for referring to information at a later stage.

1. Safety Instructions

We are not responsible for any property damage or personal injury caused by failure to observe these product notes and manual, improper handling or unauthorised modifications.

It can only be installed by a qualified electrician.

Make sure that the item has not been damaged during transport before putting the light into operation. It may not be operated if there are any damages to electrical parts.

The luminaire may only be operated completely with its protective cover.

It may only be operated once removed from the packaging.

The type plate must not be removed.

The connection lines in the building must be disconnected before installation and secured against being switched back on.

Make sure the electrical specifications for the connection lines correspond with the specifications given on the nameplate of this product.

We recommend that you protect the product with a residual-current-operated protective device. Follow all installation regulations applicable at your location.

Do not allow the product to come into contact with extreme heat or naked flames.

The product must not be covered with objects (decorations) or thermally insulating coverings /similar materials.

Before disposal of the packaging material make sure that all components are removed.

Keep packaging material away from the reach of children and pets. The packaging contains small parts that may be swallowed by children.

Track system 3-Phases 230V, Alnitak 24-30W, Article No.: 707110-707115

2. Proper Use

This product is only intended for lighting purposes and may only be operated on normal or non-flammable surfaces.

Use the product only in protected and dry interior rooms.

Make sure that the surface is suitable for permanently and reliably taking the weight of the light.

3. Care

Repairs may only be carried out by a qualified electrician.

Disconnect the entire product from the mains first and allow it to cool down before cleaning or maintaining.

Use a dry or slightly moistened cloth for cleaning.

Never use any chemicals, flammable cleaning agents or abrasives. These may cause damage to the surface coating and/or the insulators.

4. Faulty Function

Light switched on at the switch?

Transformer mounted and connected properly?

If available; remote control intact? Check the batteries.

Check the connected lines.

Lamp defective?

5. Changing Lamps

The light source of this lamp is not replaceable. When the light source has reached its end of life, replace the entire luminaire.

6. Storage and Disposal

Used electronic devices must be brought back to public collection points and must not be disposed of as household waste.


Storage in a dry and clean environment. Do not strain the product mechanically during storage.

Artikel Nr. / Article No.: 707110 / 707111 / 707112 / 707113 / 707114 / 707115

Schienensystem 3-Phasen 230V Leuchte, Alnitak / Track system 3-Phases 230V lamp, Alnitak
220-240V AC/50-60Hz, 32,00 W


Achtung! Für diese Arbeiten müssen Sie die Spannungsversorgung trennen.
Attention! For this work you must turn off the power supply.

1.




Lösen Sie die zwei Schrauben.
Loosen the two screws.

2.



Drücken Sie mit einem Schraubendreher in die Federhalterung und entfernen die Abdeckung.
Press with a screwdriver into the spring holder and remove the cover.

3.



Nehmen Sie die gewünschten Einstellungen am DIP Schalter vor. Bitte achten Sie bei der Montage der Abdeckung darauf, das Anschlusskabel nicht einzuklemmen.
Make the desired settings on the DIP switch. When mounting the cover, be careful not to pinch the connection cable.

4.

ON

1 2

DIP Schalter Einstellungen /

DIP switch settings

Ausgangsstrom / Output current	1	2	Leistung / Power
600 mA	<input type="radio"/>	<input type="radio"/>	23,00 W
700 mA	<input checked="" type="radio"/>	<input type="radio"/>	28,00 W
750 mA	<input type="radio"/>	<input checked="" type="radio"/>	30,00 W
800 mA	<input checked="" type="radio"/>	<input checked="" type="radio"/>	32,00 W